

Arm Rest Kit Instructions for 44100BK Seats

To apply **93140BK Arm Rest Kit** to **44100BK Seat**:

1. On either side of the backrest, run your finger under the vinyl to locate the three bolt locations. Mark where the center of each hole is.
2. Using a small center punch or similar tool, pierce the vinyl. NOTE: Be sure your center punch is running down the center of where the bolt hole location is.
3. Take one of the bolts and run it through the vinyl to ensure the bolt will run through it.
4. Install the armrest.
5. Repeat steps 1 through 4 for the opposite side.